



CAMPLEX SAFESOCK-1 Protective Sock User Manual

[Home](#) » [CAMPLEX](#) » CAMPLEX SAFESOCK-1 Protective Sock User Manual 

Contents

- [1 CAMPLEX SAFESOCK-1 Protective Sock User Manual](#)
- [2 Field Install Procedure for SAFESOCK](#)
- [3 CUSTOMER SUPPORT](#)
- [4 Documents / Resources](#)

CAMPLEX SAFESOCK-1 Protective Sock User Manual



Field Install Procedure for SAFESOCK

1. Carefully slide the shrink tube over cable jacket.



2. Carefully slide the Tech flex wrap over fan-out and under shrink tube – gently without bending / compromising the fiber cables.



3. Use heat gun to permanently affix cable jacket and the Tech flex sock together at the cable fan-out

DO NOT pull your cable using this component.

Please use extreme caution during install of SAFESOCK-1 as fibers are extremely fragile.

Pulling / installing fiber optic cables into conduit / walls / plenum area should only be done by a professional utilizing approved pulling solutions and tools.

CUSTOMER SUPPORT

812 Kings Highway Saugerties,

NY 12477 800-445-7568

sales@camptex.com



Documents / Resources

	CAMPLEX SAFESOCK-1 Protective Sock [pdf] User Manual SAFESOCK-1 Protective Sock, SAFESOCK-1, Protective Sock, Sock, Protective
--	--