



**CD OFFROAD**  
**Custom Dynamics**  
**SXS Turn Signal Kit**



# CD OFFROAD Custom Dynamics SXS Turn Signal Kit Installation Guide

[Home](#) » [CD OFFROAD](#) » CD OFFROAD Custom Dynamics SXS Turn Signal Kit Installation Guide 

## Contents

- [1 CD OFFROAD Custom Dynamics SXS Turn Signal Kit](#)
- [2 Product Information](#)
- [3 Product Usage Instructions:](#)
- [4 Package Contents:](#)
- [5 Installation:](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)



**CD OFFROAD Custom Dynamics SXS Turn Signal Kit**



## Product Information

### Specifications

- Part Number: CD-SXS-RZRPRO
- US Patent: D993198
- Fits: 2021-2024 Polaris RZR PRO

### Product Usage Instructions:

#### Attention Before Installation

Before installation, ensure to disconnect the negative battery cable from the battery to avoid electrical shock, injury, or fire. Secure the negative battery cable away from the positive side of the battery and all other positive voltage sources on the vehicle.

#### Safety First:

Always wear appropriate safety gear, including safety glasses, when performing any electrical work. It is highly recommended to wear safety glasses throughout the installation process. Ensure the vehicle is on a level surface, secure, and cool. Refer to each individual set of included instructions for specific notes and warnings for each part. Consult your manufacturer's service manual if unsure of any procedure.

#### Important Installation Notes

It is recommended to perform the installation in a controlled environment with a constant temperature of 70°F or above to allow proper adhesion. Allow 24 hours before riding or washing the bike after installation.

1. Disconnect the battery negative cable following the owner's manual.
2. Install CD-ATC-6 according to the included instructions.
3. Install SXS-TS-SW-1 as per the included instructions.
4. Install GEN-SMART-TPU-RZRPRO following the provided instructions for installation, wiring connections, and programming.
5. Install CD-SXS-FTS-AW according to the included instructions for installation, mounting, and wiring connections.
6. Reinstall the battery negative cable and test all lighting for proper operation before driving the vehicle.

## FAQ

### Questions?

**Email:** [Info@CustomDynamics.com](mailto:Info@CustomDynamics.com) or Call us at: 1 [800-382-1388](tel:800-382-1388) M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Valid until 05/2024

### Custom Dynamics® SXS Turn Signal Kit

#### Installation Instructions

We thank you for purchasing the Custom Dynamics® SXS Turn Signal Kit Instructions. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Number:** CD-SXS-RZRPRO US Patent D993198

### Package Contents:

- CD-SXS-FTS-AW (1)
- SXS-TS-SW-1 (1)
- CD-ATC-6 (1)
- GEN-SMART-TPU-RZRPRO (1)

**Fits:** 2021-2024 Polaris RZR PRO.

### ATTENTION

Please read before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety** First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

**Note:** Please refer to each individual set of included Instructions for specific notes and warnings for each part. Always refer to your manufacturers service manual if unsure of any procedure.

**Important:** It is recommended that the installation of this product should be performed in a controlled environment with constant temperature of 70F or above to allow proper adhesion. Allow 24 hours before riding or washing the bike.

### Installation:

1. Disconnect battery negative cable. Refer to Owners manual if unsure of the process.
2. Install the CD-ATC-6. Follow the procedure in the in-cluded instructions with the CD-ATC-6 for specifics on installation and wiring connections.
3. Install the SXS-TS-SW-1. Follow the procedure in the included instructions with the SXS-TS-SW-1 for specifics on installation and wiring connections.
4. Install the GEN-SMART-TPU-RZRPRO. Follow the proce-dure in the included instructions with the GEN-SMART-TPU-RZRPRO for specifics on installation, wiring connections and programming.

5. Install the CD-SXS-FTS-AW. Follow the procedure in the included instructions with the CD-SXS-FTS-AW for specifics on installation, mounting and wiring connections
6. Reinstall battery negative cable and test all lighting for proper operation before operating the vehicle.

Questions? Email: [Info@CustomDynamics.com](mailto:Info@CustomDynamics.com) or Call us at: 1 [800-382-1388](tel:800-382-1388) M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

## Documents / Resources

	<p><b><a href="#">CD OFFROAD Custom Dynamics SXS Turn Signal Kit</a></b> [pdf] Installation Guide CD-SXS-RZRPRO, CD-SXS-FTS-AW, SXS-TS-SW-1, CD-ATC-6, GEN-SMART-TPU-RZRPRO, Custom Dynamics SXS Turn Signal Kit, Custom Dynamics, Custom Dynamics SXS, SXS Turn S ignal Kit, Turn Signal Kit, Signal Kit, SXS</p>
---	--

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.