CTA 1189 Extra Deep Metric Socket





CTA 1189 Extra Deep Metric Socket Instructions

Home » CTA » CTA 1189 Extra Deep Metric Socket Instructions

Contents

- 1 CTA 1189 Extra Deep Metric
- **Socket**
- **2 Product Specifications**
- **3 Product Usage Instructions**
- **4 Maintenance Tips**
- 5 FAQ
- **6 INSTRUCTIONS**
- **7 Components**
- 8 Documents / Resources
 - 8.1 References



CTA 1189 Extra Deep Metric Socket



- Part Number: 1189
- Product Name: 18 Pc. Deep Metric Socket Set
- · Includes the following sizes:
 - 6mm, 7mm, 8mm, 9mm, 10mm, 11mm, 12mm, 13mm, 14mm, 15mm, 16mm, 17mm, 18mm, 19mm,
 20mm, 21mm
 - 3/8 to 1/4 Adapter
 - 1/2 to 3/8 Adapter

Product Usage Instructions

- CAUTION: To prevent injury, always wear gloves and eye protection that meet ANSI Z87.1 and OSHA standards.
- CAUTION: To prevent equipment damage, clean and lubricate threaded screws and holes before and after
 use.

Using the Socket Set

- 1. Select the appropriate socket size for the fastener you are working on.
- 2. Attach the socket to the ratchet handle securely.
- 3. Place the socket onto the fastener and turn in the desired direction to loosen or tighten.
- 4. Always work with a firm grip on the handle to avoid slippage.
- 5. After use, clean the sockets and store them in a dry place to prevent rusting.

Maintenance Tips

- Regularly inspect sockets for any signs of wear or damage.
- Keep sockets clean and free of debris to ensure smooth operation.
- If a socket becomes damaged or shows signs of wear, replace it immediately.

FAQ

- Q: Can I use this socket set for both loosening and tightening fasteners?
- A: Yes, this socket set can be used for both loosening and tightening fasteners. Simply select the appropriate size socket and attach it to a ratchet handle to perform the desired action.
- Q: How should I store the socket set when not in use?
- A: It is recommended to clean the sockets after use and store them in a dry place to prevent rusting. You can consider using a designated toolbox or case to keep the set organized and protected.

INSTRUCTIONS

18 Pc. Deep Metric Socket Set

- Full-range deep metric socket set
- · Sizes 6mm to 21mm

- 120mm long
- Broached for extra-deep reach
- Provides access to recessed areas with extra long bolts, found on valve cover bolts (7mm), diesel glow plugs (10mm, 12mm, 17mm), Benz C-Class (W204) rear bumper covers (10mm, 12mm), BMW N54 Twin-turbo valve cover bolts (12mm), BMW E90/92 Lug Nuts (17mm), BMW Spark Plugs (14mm), BMW E90/92 Clutch Bleeder Valve (11mm) & Ford 7.3L glow plugs (10mm), and more
- 3/8" & 1/2" square drive
- Includes 2 drive adapters 1/2" to 3/8" & 3/8" to 1/4"

Components

- CTA # SIZE
- 1175 6mm
- 1176 7mm
- 1708 8mm
- 1709 9mm
- 1710 10mm
- 1711 11mm
- 1712 12mm
- 1713 13mm
- 1714 14mm
- 1715 15mm
- 1716 16mm
- 1717 17mm
- 1718 18mm
- 1177 19mm
- 1178 20mm
- 1179 21mm
- 1438 3/8" to 1/4" Adapter
- 1439 1/2" to 3/8" Adapter



CAUTION: To prevent injury, always wear gloves and eye protection that standards Z87.1 and OSHA standards. **CAUTION:** To prevent equipment damage, clean and lubricate threaded screws and holes before and after use.

Documents / Resources



CTA 1189 Extra Deep Metric Socket [pdf] Instructions

1189 Extra Deep Metric Socket, 1189, Extra Deep Metric Socket, Deep Metric Socket, Metric Socket, Socket

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.