



CURT 56325 Custom Wiring Connector Instruction Manual

[Home](#) » [Curt](#) » CURT 56325 Custom Wiring Connector Instruction Manual 



The **FIRST** Name
in Towing Products™

INSTALLATION INSTRUCTIONS



WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

Contents

- [1 56325 APPLICATIONS](#)
- [2 CUSTOM WIRING CONNECTOR](#)
- [3 WIRING LOCATION GUIDE](#)
- [4 TOOLS NEEDED](#)
- [5 INSTALLATION / SAFETY INSTRUCTIONS](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

56325 APPLICATIONS

Make	Model
Cadillac	XT5
GMC	Acadia (excluding Limited)

CUSTOM WIRING CONNECTOR



WIRING LOCATION GUIDE

SUVS, MINI & FULL-SIZED VANS (S)

The representative vehicle is shown below S6 – Behind the center of the rear bumper



NOTICE

All steps must be followed to ensure the CURT wiring connector will function properly. Once installed test for proper function by using a test light or connecting a properly wired trailer.

All connections must be complete for the wiring harness to function. Test and verify the installation of product with test light or trailer after installment. For the initial test, reset the electrical system of the vehicle by temporarily removing the vehicle's key from the ignition.

TOOLS NEEDED

Wire cutter

WARNING

Exceeding the product rating can cause loss of warranty, overheating, and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits – 7.5 amps per side Tail / Running Circuits – 7.5 amps total Check the vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Locate the vehicle battery on the driver's side under the hood and disconnect the negative battery terminal.

Step 2

Locate the vehicle connector behind the rear bumper in the center of the vehicle. The connector will be similar to that on the CURT wiring connector (A).

Step 3

Separate the vehicle connectors from the weather seal connectors. Take care not to damage the locking tabs.

Step 4

Insert the CURT wiring connector end into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place.



Step 5

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out-of-the-way location. Secure any loose wires with the provided cable ties.

Step 6

Reinstall all items removed during installation and reconnect the negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

CURTMFG.COM • NEED ASSISTANCE? • 1.877.287.863
4 • 56325-INS-RA • PAGE 2



<http://qr.curtmfg.com/video/56325>
Scan for helpful installation tips

Documents / Resources

	<p>CURT 56325 Custom Wiring Connector [pdf] Instruction Manual 56325 Custom Wiring Connector, 56325, Custom Wiring Connector, Wiring Connector, Connect or</p>
--	--

References

-  [CURT: Trailer Hitches - Trailer Wiring - 5th Wheel - Gooseneck](#)