

Custom Dynamics High Power Driving Light Bar Instruction Manual

Home » Custom Dynamics » Custom Dynamics High Power Driving Light Bar Instruction Manual



Contents

- 1 Custom Dynamics High Power Driving Light
- **2 Installation Instructions**
- 3 Package Contents
- **4 ATTENTION**
- **5 Installation**
- 6 Documents / Resources
- 7 Related Posts



Custom Dynamics High Power Driving Light Bar



Installation Instructions

We thank you for purchasing the Custom Dynamics® High Power Driving Light. Our products utilize the latest technology and high-quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during the installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: LB-HP-W-2

Package Contents

- High Power Driving Light Bar (1)
- Mounting Bracket (1)
- 4MM Allen Wrench (1)
- M5 x .8 x10 Bolt (2)
- M5 x .8 Nut (2)
- Fits: 06-17 Harley Davidson Dyna with 49 mm front ends, 00-17 Softail with 41 mm front ends. Additional fitments when using LB-HP-BRACKET (Sold Separately) 87-21 Sportster, 99-05 Dyna, and 87-95 FXR models with 39mm narrow glide front ends.

ATTENTION

Please read all information below before Installation

Warning: Disconnect the negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from the positive side of battery and all other posi-tive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear includ-ing safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equip-ment lighting.

Note: Off-road use only. Always check federal, state, and local laws before modifying your motorcycle.




Installation

 Remove the seat and battery side cover. Discon-nect the negative battery terminal. Refer to your owner's manual if unsure of the process.

- 2. Protect the front fender with a towel or fender cover to prevent damage to the painted surface during installation.
- 3. Locate the headlight mounting bolt underneath the bottom triple tree. Loosen the bolt and re-move.





- 4. Install the Driving light bar bracket on the tri-ple tree by reinstalling the OEM headlight mounting bolt. Refer to Photo 1.
- 5. Insert the provided nuts into the slots on the back of the High Power Driving Light bar. In-stall the High Power Driving light bar onto the bracket using the provided mounting bolts. Do not fully tighten, thread until snug. Reference Photo 2.
- 6. If using with our LB-HARN-UNV (sold sepa-rately) installation harness, Connect the High Power Driving Light Bar wiring harness to the LB-HARN-UNV harness after it is installed and skip to Step 7.
- 7. If hardwiring to the bike, Cut the plug and play JAE connector from the Driving Light bar. Strip back the wires

and connect the Red to a switched +12vdc fused power source. Connect the Black to a negative ground.

- 8. Reconnect the battery negative cable. Rein-stall the seat and battery side cover.
- 9. Adjust the Driving Light bar and tighten the screws to secure in place. Reference Photo 3.
- 10. Test operation of all lighting before riding.

Questions? Call us at 1 (800) 382-1388 M-TH 8:30 AM-5:30 PM / FR 9:30 AM-5:30 PM EST

Documents / Resources



<u>Custom Dynamics High Power Driving Light Bar</u> [pdf] Instruction Manual High Power Driving Light Bar, High Power Light Bar, Driving Light Bar, Light Bar, Light, Bar, Driving Light Bar, Light Bar, Light, Bar, Driving

Manuals+, home privacy