




Dobinsons DD59-542K Diff Drop Kit Installation Guide

[Home](#) » [Dobinsons](#) » [Dobinsons DD59-542K Diff Drop Kit Installation Guide](#) 



Diff Drop Kit Install Guide

Part Number: DD59-542K

Fitment:

Toyota Tundra 3rd Gen

Toyota Sequoia 3rd Gen



Contents

- 1 DD59-542K Diff Drop Kit
- 2 Documents / Resources
 - 2.1 References

DD59-542K Diff Drop Kit

This Diff Drop Kit will take approximately 1-2 hours to install

Dobinsons products should be installed by a qualified installer, and it is the installers responsibility to ensure correct fitment.

Dobinsons is not responsible for any damage incurred to the vehicle during installation.

1. Securely support the diff with a screw jack before removing and bolts / nuts.
2. Remove both OEM diff brackets.
3. Install the driver's side bracket using the supplied shim spacer and bolts.

NOTE** NOTE** Install the top bolt on the diff side first, using a thin wall socket and hand tighten, Use a pry bar to locate the rubber bushing on the frame.

4. Install the supplied axle side bracket using OEM bolts and supplied nuts.
5. Torque all hardware to OEM spec.







Documents / Resources



[Dobinsons DD59-542K Diff Drop Kit](#) [pdf] Installation Guide
DD59-542K Diff Drop Kit, DD59-542K, Diff Drop Kit, Drop Kit, Kit

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.