

eurowise 996 Subframe Drop Kit Installation Guide

Home » eurowise » eurowise 996 Subframe Drop Kit Installation Guide 🖫



eurowise 996 Subframe Drop Kit



ALWAYS PRACTICE SAFE PROCEDURES WHEN WORKING UNDER THE VEHICLE **USE JACK STANDS AT ALL TIME!** PROFESSIONAL INSTALLATION HIGHLY SUGGESTED.

Contents

- 1 DISCLAIMER
- 2 PARTS
- 3 INSTALLATION

INSTRUCTIONS

- **4 CUSTOMER SUPPORT**
- 5 Documents / Resources
 - **5.1 References**

DISCLAIMER


This installation guide is provided for informational purposes only. We are not responsible for any damages or injuries resulting from improper installation or use of this product. It is essential to follow all safety guidelines and maintain safe installation habits. We strongly recommend that you consult with or hire a professional installer to ensure proper installation. Use this guide at your own risk.



If you have an early model 996, you may end up with 2 additional spacers and bolts. You will not need these as they are for later models with a different subframe.

PARTS





INSTALLATION INSTRUCTIONS
























This one is a bit tucked in and hidden but there's one here.

CUSTOMER SUPPORT

441 SPRINGBROOK ROAO. CHARLOTTE, NC 20217 704-559-8100
INFO@EURO.COM
WWW.EUROWISE.COM
SHOP.EUROIMISE.COM



Documents / Resources



<u>eurowise 996 Subframe Drop Kit</u> [pdf] Installation Guide 911, 996 Subframe Drop Kit, 996, Subframe Drop Kit, Kit

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.