

# eurowise Cayenne and Touareg Trunk Rail System Installation Guide

Home » eurowise » eurowise Cayenne and Touareg Trunk Rail System Installation Guide 🖺



#### **Contents**

- 1 eurowise Cayenne and Touareg Trunk Rail **System**
- **2 Product Specifications**
- **3 Product Usage Instructions**
- 4 Frequently Asked Questions (FAQ)
- **5 Product includes Quantity**
- **6 INSTALLATION INSTRUCTION**
- **7 ANY QUESTIONS**
- 8 Documents / Resources
  - 8.1 References
- 9 Related Posts



## eurowise Cayenne and Touareg Trunk Rail System



### **Product Specifications**

• Quantity: 2 Aluminum Rails, 4 Mounting Brackets, 8 M6 Bolts

• Manufacturer: Eurowise

• Model: Cayenne and Touareg Trunk Rail System

#### **Product Usage Instructions**

- 1. Remove factory trunk brackets on all four corners using a T30 torque bit.
- 2. Drill out using a 1/8 inch drill bit.
- 3. Punch out using a punch or screwdriver and remove the D shape bracket.
- 4. Pass the included bracket through the opening created.
- 5. Test fit the bracket before bolting the rail system to confirm proper positioning.
- 6. Install the rails using the supplied bolts and torque to 10 foot-pounds.
- 7. Reinstall into the vehicle and reinstall the OEM Torx screws.
- 8. Note: If you have a diesel Touareg model, the rail height may differ from the photos.

### Frequently Asked Questions (FAQ)

· What tools are needed for installation?

You will need a T30 torque bit, 1/8 inch drill bit, punch or screwdriver, and appropriate wrench for tightening bolts.

• Can the rail system be installed on other vehicle models?

The rail system is specifically designed for use with Cayenne and Touareg models and may not be compatible with other vehicles.

How can I contact customer support for further assistance?

For any questions, comments, or concerns related to your product, please contact Eurowise at 704-559-8100 or email info@eurowise.com.

#### **Product includes Quantity**

- · 2 Aluminum Rails Quantity
- 4 Mounting Brackets Quantity
- 8 M6 Bolts.

#### INSTALLATION INSTRUCTION

Remove Factory trunk brackets on all four corners using T 30 torque bit.



• Needs to be drilled out using 1/8 inch drillbit.



 You can punch out using a punch or screwdriver and pull out the rest of the way you will dispose of this and the D shape bracket that is removed.





• Pass the included bracket through the opening that is created.



• Test fit it before bolting the rail system on to confirm it is clocked in the right position. Do not tighten it down as you will install the rails next.





 Now install the rails using supplied bolts torque to 10 foot pounds now reinstall into vehicle and reinstall the OEM Torx screws.







- If you have a diesel, Touareg model, it will have a different height rail from the photos.
- Thanks for your purchase. Email us for any questions.

## **ANY QUESTIONS**

IF YOU HAVE ANY QUESTIONS, COMMENTS, OR CONCERNS RELATED TO YOUR PRODUCT PLEASE CONTACT US!

- 440 SPRINGBROOK ROAD
- CHARLOTTE, NC 28217
- 704-559-8100
- INFO@EUROWISE.COM
- WWW.EUROWISE.COM
- SHOP.EUROWISE.COM

#### **Documents / Resources**



<u>eurowise Cayenne and Touareg Trunk Rail System</u> [pdf] Installation Guide Cayenne and Touareg Trunk Rail System, Touareg Trunk Rail System, Trunk Rail System, Rail System, System

#### References

- Specializing in European Service, Performance and Fabrication Eurowise Performance
- S Eurowise Audi, BMW, Volkswagen, Mercedes, & Porsche Service
- User Manual

#### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.