



iBoard IB-097 Running Boards Nerf Bars Side Steps Step Bars Installation Guide

[Home](#) » [iBoard](#) » iBoard IB-097 Running Boards Nerf Bars Side Steps Step Bars Installation Guide 

iBoard IB-097 Running Boards Nerf Bars Side Steps Step Bars Installation Guide



READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. ASSISTANCE IS RECOMMENDED.

- ROCKER PANEL MOUNT
- NO DRILLING REQUIRED

Fastener Size	Tightening Torque (ft-lbs)	Required
6mm	6-7	X
8mm	16-18	√
10mm	31-32	√
12mm	56-58	X
14mm	92-94	X

Contents

1

PART LIST

2

Step Bar Assembly:

3

Assembled Step Bars


4

Documents / Resources

4.1










References

PART LIST



Scan for Installation Video



Hardware Package A (For Bracket Installation)					
Item	QTY	Description	Item	QTY	Description
1#	2	M10X35 Bolt Plates 	6#	6	M10 Hex Nuts 
2#	2	M10 Plastic Washers 	7#	12	M8X1.25-30mm Hex Bolts 
3#	4	M10X1.5-30mm Hex Bolts 	8#	12	M8 Flat Washers 
4#	10	M10 Flat Washers 	9#	12	M8 Lock Washers 
5#	6	M10 Lock Washers 			


Hardware Package B (For Stainless Steel Step Bar Installation)					
Item	QTY	Description	Item	QTY	Description
1#	20	M8X1.25-35mm Carriage Bolts 	3#	20	M8 Nylon Lock Nuts 
2#	20	M8 Large Flat Washers” 	4#	10	Sliders (Packed with Step Bars) 

Hardware Package C (For Stainless Steel Step Bar Assembly)					
Item	QTY	Description	Item	QTY	Description
1#	8	Plastic Rivets 	5#	4	M8 Hex Nuts 
2#	12	M8X1.25-25mm Inner Hex Bolts 	6#	2	Plastic Covers (Packed with Step Bars) 
3#	16	M8 Flat Washers 	7#	2	Back Plates (Packed with Step Bars) 
4#	12	M8 Lock Washers 			

STEP 1

Step Bar Assembly:


1. Select and assemble (2) Step Bars with (2) M8X1.25-25mm Inner Hex Bolts, (4) M8 Flat Washers, (2) M8 Lock Washers and (2) M8 Hex Nuts, **(Fig 1)**.



(Fig 1) Step Bars Assembly


NOTE: (4) Step Bars are universal.

2. Attach (1) Back Plate to the bottom of the installed (2) Step Bars with (4) M8X1.25-25mm Inner Hex Bolts, (4) M8 Flat Washers, (4) M8 Lock Washers, **(Fig 2)**.



(Fig 2) Back Plate Installation

3. Install (1) Plastic Cover to cover the joint of (2) Step bars with (4) Plastic Rivets, **(Fig 3)**.



(Fig 3) Plastic Cover Installation (Bottom View)

4. Repeat to assemble the other (2) Step Bars.

Assembled Step Bars



STEP 2

Start the installation from the driver side of the vehicle, remove the existing (2) factory bolts, (or plastic plugs), on the side panel located by the front tire opening, **(Fig 4)**.


This will be the mounting location for the driver side front Mounting Bracket.



(Fig 4) Driver Side Front Mounting Location

STEP 3

Select the Driver Front Mounting Bracket (DFM). Attach the Bracket to the vehicle using the included (2) M8X1.25-30mm Hex Bolts, (2) M8 Lock Washers and (2) M8 Flat Washers. Don't fully tighten at this time, **(Fig 5)**.



(Fig 5) Driver Front Mounting Bracket Installed

STEP 4


Move along the side panel to the driver side center mounting location, **(Fig 6)**.



(Fig 6) Driver Side Center Mounting Location

Repeat Steps 2-3 to install the Driver Center Mounting Bracket (DCM), **(Fig 7)**

(2) M8X1.25-30mm Hex Bolts
(2) M8 Lock Washers
(2) M8 Flat Washers



(Fig 7) Driver Center Mounting Bracket Installed

STEP 5


Next, move to the 4th mounting location at the back of the cab. Repeat Steps 2-3 to install the Driver Center Mounting Bracket (DCM).

IMPORTANT: There are (4) mounting locations along the side of the vehicle. Installation will use the 1st, 2nd and 4th mounting locations only

STEP 6

Assemble (1) Driver Rear Mounting Bracket (DRM) and (1) Driver Rear Bar Bracket (DRB) with (2) M10X1.5-


30mm Hex Bolts, (2) M10 Lock Washers, (4) M10 Flat Washers and (2) M10 Hex Nuts, (**Fig 8**). Do not fully tighten hardware at this time.




(Fig 8) Driver Rear Brackets Assembly

STEP 7

Move to the very end of the cab. Locate and remove the rubber plug in the side of the inner body panel, (**Fig 9**).




Select (1) M10X35 Bolt Plate and (1) M10 Plastic Washer, insert the Bolt Plate into the hole and thread the Plastic Washer down onto the Bolt Plate until it is tight against the body panel, (**Fig 10**).



NOTE: The Plastic Washer is designed to prevent the Bolt Plate from falling into the body panel and to aid Support Bracket installation.

Select (1) M10 Flat Washer and slide it onto the threaded end of the Bolt Plate over the Plastic Washer, **(Fig 11)**. Next, secure the assembled driver rear bracket to the Bolt Plate with (1) M10 Flat Washer, (1) M10 Lock Washer and (1) M10 Hex Nut, (Fig11). Do not fully tighten hardware at this time.



STEP 8

Once all (4) Driver side mounting brackets are installed, then proceed to the Step Bar installation. (**Figs 12 & 13**)

1. Select (1) Slider and (2) M8X1.25-35mm Carriage Bolts;
2. Install (2) M8X1.25-35mm Carriage Bolts in (1) Slider.
3. Slide the Slider (with carriage bolts) to the Step Bar.
4. Repeat to install the other (3) sliders to the step bar.
5. Attach the Step Bar (with the Sliders) onto the installed mounting brackets. Position the Sliders to the installed brackets. Secure the Step Bar to the installed Brackets by using (10) M8 Large Flat Washers and (10) M8 Nylon Lock Nuts and (5) Sliders, (**Fig 13**). Do not fully tighten hardware at this time.


Note: The Sliders are packed with the Step Bars.


Level and adjust the Step Bar and fully tighten all hardware.

Repeat Steps 2-8 for the other side Step Bar installation. The installation is completed!!!


Attention

Do periodic inspections to the installation to make sure that all hardware is secure and tight.
In order to protect your bars/boards, please use mild soap/non-abrasive products for cleaning only.






Front and Center Brackets
(Bottom View)



Rear Bracket
(Bottom View)

iBoard®

Documents / Resources



[iBoard IB-097 Running Boards Nerf Bars Side Steps Step Bars](#) [pdf] Installation Guide
 IB-097 Running Boards Nerf Bars Side Steps Step Bars, IB-097, Running Boards Nerf Bars Side Steps Step Bars, Boards Nerf Bars Side Steps Step Bars, Nerf Bars Side Steps Step Bars, Side Steps Step Bars, Steps Step Bars, Step Bars

References

- [User Manual](#)

