



LOCKER DOWN LD2011X Console Safe Instruction Manual

[Home](#) » [LOCKER DOWN](#) » LOCKER DOWN LD2011X Console Safe Instruction Manual 



Security Products
INSTALLATION INSTRUCTIONS
LD2011X/LD2011XEX

Contents

- [1 LD2011X Console Safe](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

LD2011X Console Safe

[2007-2014 Chevrolet Silverado, Suburban, and Tahoe/ GMC Sierra, Yukon, and Yukon XL with Less Brackets]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the DOOR OPEN in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the 4 screws that are holding down the center console.
4. Insert the lid assembly diagonally with the lock facing forward towards the dash, then turn the lid assembly inside the console so that the outline matches with the console compartment outline (see images on back for exact orientation).

5. With the lid OPEN, insert the right-side bracket first (this is the side with the USB cable), then the left side bracket (see images on back for side descriptions)
 - a. Once the sides are inserted over the bolts on each side of the lid assembly, apply the LOCK'ER DOWN provided nuts to each of the four bolts.
6. After the left and right brackets are inserted, insert the rear bracket (see image on back for reference)
 - a. To ensure this bracket is properly fit, make sure the insert is flush over the left rear factory console screw hole, and use the FACTORY SCREW to fasten the bracket down.
7. After the rear bracket is installed, insert the front bracket (see image on back for reference)
 - a. To ensure this bracket is properly fit, make sure the insert in the bracket is flush over the front left factory console screw hole, and use the FACTORY SCREW to fasten the bracket down.
8. Finally place the connector strap (see image on back for reference) to connect the front and the rear brackets to each other and apply the LOCK'ER DOWN provided acorn nuts to each stud using the 7mm socket bit.
9. Using an IMPACT DRILL or SCREWDRIVER, apply the 4 self-tapping screws into each of the four slots (2 on the bottom section of each bracket) and through the floor of the console.
10. Remove the padding from the bottom of the inside of the safe.
11. Tighten the screws and nuts, DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE OR SAFE!
12. Enjoy your purchase!



Tools Needed:

- IMPACT DRILL or SOCKET WRENCH, SCREWDRIVER
- 13mm Socket bit
- 8mm Socket Bit

Contents Included: 4 11mm Nuts.
4 Black Self Tapping Screws.
2 Acorn Nuts.



Image 1: Diagonal Orientation for in stallment

Image 2: Assembly orientation after turning the to fit.

Image 3: Left Side Bracket



Image 4: Right Side Bracket

Image 5: Rear Bracket

Image 6: Front Bracket



Image 7: Connector Bracket

Image 8-9: Internal Bracket Orientation (left image is b ack, right image is bottom)

**LOCKER
DOWN**®

Documents / Resources

[illegible]

LOCKER DOWN LD2011X Console Safe [pdf] Instruction Manual
LD2011X Console Safe, LD2011X, Console Safe, Safe

Manuals+,