

**THANK YOU FOR
BUYING OUR ROLBAG
PRO PLUS**

buds-sports.com

INSTRUCTION MANUAL



HOW TO PACK YOUR BIKE WITH YOUR ROLBAG PRO PLUS



PLACE THE TWO RIGID REINFORCEMENTS ON THE SIDES OF THE BAG (HONEYCOMB BOARD ON THE WHEELS SIDE AND PE BOARD ON THE OPPOSITE SIDE).



FRAMEPROTECT - EASY TO USE, WRAP IT AROUND THE FRAME

**FORK BIKE PROTECT -
EASY TO INSTALL, JUST
REMOVE THE FRONT
WHEEL AND PLACE IT ON
THE BIKE FORK AND
BUCKLE IT FIRMLY**

**REAR BIKE PROTECT -
FAST TO INSTALL ON
THE REAR DERAILLEUR,
AFTER REMOVING THE
REAR WHEEL**

**PADDED WHEEL POCKETS
- INCLUDED ON BOTH
SIDES, USE THE VELCRO TO
SECURE BOTH WHEELS**

**UNIVERSAL SUPPORT - PROTECTS
THE BOTTOM RACKET AND
PREVENTS TEARING CAUSED BY
PROTRUDING BIKE PARTS**

**HANDLEBAR PROTECT - SUITABLE
FOR MTB AND STRAIGHT
HANDLEBAR, SIMPLE TO USE,
WRAP IT AROUND THE
HANDLEBAR AND SECURE IT WITH
VELCRO**



- 1 REMOVE THE WHEELS FROM THE BIKE AND STORE THEM IN THEIR DESIGNATED POCKETS.**
- 2 INSTALL THE FRAME PROTECT, FORK PROTECT, UNIVERSAL SUPPORT, HANDLEBAR PROTECT FOR RIGHT-HAND HANDLEBARS AND REAR BIKE PROTECT ON THE BIKE.**
- 3 TURN THE HANDLEBARS THROUGH 90° SO THAT THE HANDLEBARS ARE ALIGNED WITH THE AXIS OF THE TOP TUBE**
- 4 INSTALL THE BIKE IN THE COVER**
- 5 PUT YOUR BELONGINGS (SHOES, HELMET, ETC.) IN THE STORAGE POCKET AND STORE IT IN THE COVER.**
- 6 CLOSE THE BAG, YOU'RE DONE!**





UNIVERSAL SUPPORT - EASY TO INSTALL, PUT IT UNDER YOUR BOTTOM RACKET WITH THE LOGO OPPOSED AND BUCKLE IT FIRMLY



FORK BIKE PROTECT - EASY TO INSTALL, ONCE THE FRONT WHEEL IS REMOVED SIMPLY INSTALL THE FORK PROTECT TO THE BIKE FORK AND BUCKLE IT FIRMLY



REAR BIKE PROTECT - THE PROTECTOR IS INSTALLED ON THE REAR DERAILLEUR ONCE THE WHEEL IS REMOVED. PADDED, HINGED PROTECTOR





HANDLEBAR PROTECT - FOR MTB AND STRAIGHT HANDLEBAR. EASY TO USE, WRAP AROUND THE HANDLEBAR AND SECURE IT WITH VELCRO.



FRAMEPROTECT - EASY TO INSTALL, WRAP IT AROUND YOUR BIKE FRAME AND SECURE IT WITH VELCRO

