



Installation Guide: Barcelona Porcelain

Elon® **ALWAYS** recommends that all installations be done in accordance with local building codes and adheres to Tile Council of North America specifications.

Preparation

Prior to installation of Porcelain:

- All Porcelain should be blended from multiple cartons prior to installation.
 - On large jobs, always blend material from multiple pallets to confirm all material is from the same dye lot.

Installation

When installing Porcelain:

- For large-format porcelains:
 - Use a latex modified thinset, applying it to the substrate in a single direction to prevent air pockets.
 - Single direction troweling aids in air escape, minimizing lippage.
 - With larger tile sizes, substrate variation is less tolerated from the required plane.
- Porcelain rectangles with sides of 18" or larger to mitigate lippage due to warpage.
 - Follow TCNA recommendations for a staggered pattern joint with a 33% offset or a 1/3 - 2/3 pattern layout.
 - Adhere to an allowable tolerance of 1/32" lippage for joint sizes between 1/16" - 1/14".
- When used in showers or tubs, Porcelain should never be set with the bottom course extending into the shower base or tight to tub lip. Always leave a minimum gap of 1/4" above and perpendicular to the floor or lip of the tub or shower base and use a waterproof flexible sealant where they meet per TCNA specification B412-23.
- For pre-scored porcelain or ceramics like "Barcelona":
 - When determining grout joint width during installation, replicate the width of the scored groove in the tile for uniformity.
 - Grout the pre-scored groove with the same grout used between tiles.
- For porcelain field tile and mosaics with fiberglass mesh backs, always use Latex Modified Thinset to ensure proper adhesion to both the porcelain and mesh backing.

Grouting

Grouting Barcelona Porcelain:

- When laying out the installation, adhere to Tile Council of North America's recommendation for a minimum 1/16" grout joint.
- Elon® Tile & Stone suggests that Barcelona Porcelain be grouted with 100% Epoxy Grout and Mortar which meets A118.3 specifications similar to:
 - *Kerapoxy CQ* by Mapei
 - *CEG Lite 100% Solids Epoxy Grout* by Custom Building Products.
 - *Accu Color EFX Epoxy Special Effects Grout* by TEC
 - *EzPoxy EzClean 100% Solids Epoxy Mortar & grout* by Bostik
- Be sure to follow the manufacturer's directions for mixing and do not over wash grout joints.
 - Elon® recommends
 - First wash done using a wet sponge rubbing on a diagonal to avoid washing out grout joints.
 - Second wash substitute the sponge for a wet white cotton cloth wrapping it around the face of a hard rubber float.
 - Remove excess grout residue by rubbing in a vigorous circular motion keeping the grout joints filled flush.

Sealing

Sealing of 100% Solids Epoxy Grout is unnecessary.

Installation is Acceptance

Tile Installation Guide provided by Elon® Tile & Stone is intended solely for educational purposes. Users must understand that the information herein is not a substitute for professional advice. Elon® Tile & Stone does not assume any responsibility for the accuracy, completeness, or outcomes resulting from the application of the guidelines provided. Users utilize this guide at their own risk. It is imperative to consult with qualified professionals and adhere to specific product guidelines for optimal results. Elon® Tile & Stone, its employees, and affiliates expressly disclaim any liability for direct, indirect, or consequential damages arising from the use of this guide.