

1



Use a 5mm drill bit to pre-drill mounting holes for the top track where necessary.

2



Peel Plastic off top and bottom tracks.
Align the top track flush with the front of your door jamb. Screw the top channel to header, ceiling or door jamb with screws provided.

3



Position the bottom track ensuring it is placed **5mm** in from the front of the wardrobe before securing. If a packer has been provided, this needs to be screwed/glued to the hard surface under the bottom track first. When ready to secure, peel off the backing of the double-sided tape and mount in place.

4



Slip the top of door into rear channel then set bottom onto the rear floor track by pushing up the bottom wheels to help slot in place. Repeat for second door using the front channel.

5



Pull up the bump stop enough to reveal the adjusting hole. Use a 4mm allen key to adjust wheels. (**Clockwise** to raise or **Anti-clockwise** to lower). This adjustment helps ensure the doors align properly with the door jambs.