

CMM Universal A-Pillar Ball Mount

Installation Instructions

Thank you for purchasing the CMM Universal A-Pillar Ball Mount!

You will need: 9mm or 10mm (varies upon vehicle) socket with an extension of at least 2 inches & a 8mm Allen wrench

USE CAUTION WORKING NEAR THE WINDSHIELD!!

- STEP 1** Remove Upper or lower cover plate from the A-Pillar Handle with a flat blade screwdriver or a trim removal tool
- STEP 2** Use a 9mm or 10mm (this may vary per vehicle) socket to remove the factory bolt.
- STEP 3** Reinstall our Universal A-Pillar Ball Mount and tighten by hand until snug. Then use your 8mm Allen Wrench to add a 1/2 to 3/4 turn more to secure.

If you have a sPod and/or a hands free mic, use caution to not crush the wires between the stanchion and the A-pillar frame.

ENJOY YOUR NEW Universal A-Pillar Ball Mount!

If you have any technical questions, please feel free to call: (704) 213-4319

