

ASSEMBLY INSTRUCTION

STEP:1 	STEP:2 		STEP:3 	STEP:4 							
STEP:5 	1 x1	2 x2	3 x1	4 x1	<table> <tr> <td data-bbox="553 975 829 1354"> A M6x16mm x4 </td><td data-bbox="829 975 1094 1354"> B #5 x1 </td><td data-bbox="1094 975 1371 1354"> C M6x35mm x4 </td><td data-bbox="1371 975 1647 1354"> D M6x14x1.5mm x8 </td><td data-bbox="1647 975 1913 1354"> E x8 </td><td data-bbox="1913 975 2200 1354"> F M8x20mm x4 </td></tr> </table>	A M6x16mm x4	B #5 x1	C M6x35mm x4	D M6x14x1.5mm x8	E x8	F M8x20mm x4
A M6x16mm x4	B #5 x1	C M6x35mm x4	D M6x14x1.5mm x8	E x8	F M8x20mm x4						

Please be careful not to scratch the part itself when removing the non-woven protective film.