


### **CAUTION**

THIS GO KART WAS
SHIPPED WITHOUT
ENGINE OIL. ALWAYS
FILL WITH THE
CORRECT AMOUNT AND
GRADE OF ENGINE OIL
AS LISTED IN THE
OWNER'S MANUAL

# ASSEMBLY/PRE-RIDE INSPECTION INSTRUCTIONS



FOR QUESTIONS ABOUT THESE ASSEMBLY INSTRUCTIONS, CALL COLEMAN POWERSPORTS 888-405-8725

## **A** WARNING

NEVER ATTEMPT TO START THIS GO KART WITHOUT READING AND UNDERSTANDING THE OWNER'S/ OPERATOR'S MANUAL. THE OWNER'S OPERATOR'S MANUAL PROVIDES INFORMATION ON SAFETY, PARTS, FUNCTIONS, PRE-RIDE INSPECTION, STARTING AND MAINTENANCE

#### REMOVAL FROM CRATE

- 1. Remove metal crate from around Go-Kart.
- 2. Locate and Remove Owner's/ Operator's manual, Set up instructions and all documentation.

Note: Read Owner's / Operator's manual thoroughly before starting Go-Kart for the first time.

3. Locate and remove all parts and hardware from crate and set aside.

Note: Some hardware may already be mounted at part locations on the Go-Kart. This hardware will need to be removed then re-attached during assembly.



HARDWARE PACK



Front Tires





Rear guide bar

#### FRONT SHOCK ASSEMBLY


Hardware:

M10 X 45 bolts 4ea. (1)


M10 Lock Nuts 4 ea. (2)

Note: The center of the Go-kart will need to be lifted to install shocks, spindles and wheels. This can be done with a floor jack.

1. Attach shocks on each side of front assembly to top shock mounts with M10 bolts (1) and Lock Nuts (2)



#### Install Locations



#### FRONT WHEEL INSTALLATION


#### **HARDWARE**


M10 Lug Nuts - 8pcs (1)





- 1. Install front tires with valve stems facing out. Ensure tread pattern is facing forward (2).
- 2. Secure each tire onto each front hub(3) using 4 M10 Lug Nuts(1).
- 3. Tighten Lug Nuts to 29 ft.lbs(40Nm) on all four tires.





#### SEAT INSTALLATION

#### Seat Hardware

M8 X 50mm bolts 2ea. (5)

M8 Large Flat washers 6ea. (6)


M8 lock washers 6 ea. (7)

M8 Nuts 6 ea. (8)




hook connectors

2. Install driver side seat by sliding seat into place using front hook connector on seat brackets then bolt into place using bolts (5), Flat Washers (6) lock washers (7) and nuts (8).



3. Install passenger seat by inserting the 4 M8 bolts located on bottom of seat into the holes located on the frame. Attach seat with flat washers (6), lock washers (7) and nuts (8)

#### **BRUSH GUARD INSTALLATION**



is completey assembled.

#### FRONT BUMPER NSTALLATION

M8 X 60 bolts 2 ea. (1)


M8 X 55 bolts 2 ea. (2)


M8 Lock Nuts 4 ea. (3)

M8 Concave Spacers 4 ea. (4)

1. Attach Front Bumper(5) to Frame with M8X 60 bolts (1), M8 X 55 bolts (2), Concave Spacers (4) and Lock Nuts (3).







#### OIL COOLER INSTALLATION

M6 X 20 bolts 2 ea. (1)


M6 X 30 bolts 2 ea. (2)

M6 Lock Nuts 4 ea. (3)



1 2 3

1. Attach Oil Cooler(4) to Frame and Rear guide bar with M6 X 20 bolts (1), M6 X 30 bolts(2), and Lock Nuts (3).



# **M** WARNING

NEVER ATTEMPT TO START THIS GO KART WITHOUT READING AND UNDERSTANDING THE OWNER'S/ OPERATOR'S MANUAL. THE OWNER'S/ OPERATOR'S MANUAL PROVIDES INFORMATION PROVIDES INFORMATION ON SAFETY, PARTS, FUNCTIONS, PRE-RIDE INSPECTION, STARTING AND MAINTENANCE



(888) 405-8725 1775 E. University Dr., Tempe, AZ 85281 www.colemanpowersportsusa.com

www.facebook.com/colemanpowersportusa.com www.instagram.com/colemanpowersports\_usa



