




Hitch Installation Instruction

REV.20240701

Part#	HT-X30908	Application	For 1996-2020 Isuzu Hombre\1983-2004 Chevrolet S10\1983-1990 GMC S15\1991-2004 GMC Sonoma						
Hardware List		Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Hitch Parts		A	Hitch Body	1		B/C	Mounting Brackets	2	B-Driver Side C-Passenger Side
HW B (For Hitch Installation)		1#	Conical Washers	6	M12	4#	Hex Flange Nuts	2	M12X1.75
		2#	Hex bolts	6	M12X1.75-50	5#	Flat Washers	12	M12
		3#	Hex Nuts	6	M12X1.75	6#	Hex Bolts	2	M12X1.75-45
HW A (For Hitch Assembly)		7#	Hex Bolts	8	M12X1.75-35	9#	Hex Flange Nuts	8	M12
		8#	Flat Washers	16	M12				

Gross Load Capacity When Used As A Weight Carrying Hitch:4000 LBS. Trailer Weight & 400 LBS. Tongue Weight.
Gross Load Capacity When Used As A Weight Distribution Hitch:6000 LBS. Trailer Weight & 600 LBS. Tongue Weight.
*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.** ***

Drilling Not Required
Trimming Not Required





The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Hitch Installation Instruction

REV.20240701

Part#	HT-X30908	Application	For 1996-2020 Isuzu Hombre\1983-2004 Chevrolet S10\1983-1990 GMC S15\1991-2004 GMC Sonoma
-------	-----------	-------------	---



Step	Description
1	Assemble Hitch Body (A) and Mounting Brackets (B, C) with (8) M12X1.75-35mm Hex Bolts, (16) M12 Flat Washers, (8) M12 Hex Flange Nuts.(Hardware in "HW A").
2	<u>SPORTSIDE BED MODELS</u> Note: Some spare tires may need to be lowered and re-positioned for hitch installation. 1) Remove bumper bracket bolts. 2) Position the hitch on frame and install fasteners as shown above.
3	<u>STEP BUMPER MODELS</u> 1) Remove bumper, leaving brackets attached to frame. Disconnect bumper wiring and remove bumper. Note: Pre-1994 models, bumper is attached to each bracket by two horizontal bolts. 1994-1997 models, bumper is attached to each bracket by two vertical bolts. 1998-present, remove plastic tread from top of bumper. The bumper is attached with four vertical bolts.
4	Remove bumper brackets from frame. Remove bumper wiring guides from bumper brackets.
5	If installing hitch on an early model vehicle using a cradle storage system for the spare tire, mark the spare tire carrier 1/8" inboard of outer frame edge. Lower spare tire and cut off carrier along previously marked line.
6	Position receiver on frame and loosely install bumper brackets using (3) M12 bolts and fasteners per side. Receiver brackets are positioned between bumper brackets and frame.
7	Pre-1994 models, reinstall bumper on bumper brackets with original bolts, using (3) flat washers at each bolt location as spacers between brackets and bumpers. (see above)
8	Raise spare tire back into position and secure. Reconnect bumper wiring.
9	Torque M12 fasteners to 86 lb-ft.
***Periodically Check The Receiver Hitch To Ensure That All Fasteners *** Are Tight & All Structural Components Are Sound.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!