

ITEM NO. :T7269-2CU

ASSEMBLY INSTRUCTIONS

- 1.Attach the frame (B) to the screw on the lamp body (A) using the nut (C) to secure.
- 2.Attach the fabric shade (D) to the screw on the lamp body (A) using the nut (E) to secure.

