ASSEMBLY INSTRUCTIONS

MODEL: B850-EKB **EASTERN KING (4+8)**

(Box 1)


BOX OF HEADBOARD & FOOTBOARD

No	ITEM	Qty			
A	Headboard	1 pc			
В	Footboard	1 pc			
С	Headboard Leg	2 pcs			
D	Bed Slats	4 pcs			
Е	Bed Slats Support	8 pcs			
F	Side Rail	2 pcs			


(Box 1)

HARDWARE LIST

HAKDW	HARDWAKE LIST				
No	ITEM	Qty			
1	JCBC M6 x 40mm	4 pcs			
2	SPRING WASHER 1/4" Blk	4 pcs			
3	Flat Washer 1/4"ID x 13mmOD Blk	4 pcs			
4	ALLEN KEY m4x65mm Blk	1 pc			
5	ALLEN KEY m5x65mm Blk	1 pc			
6	Csk m4 x 32mm Rbw	16 pcs			




STEP 2: Hook SIDE RAIL(F) TO HEAD BOARD (A) closely and push down to fit. repeat step 2 with other end of rail to hook onto FOOTBOARD (B).



 $\begin{tabular}{l} \textbf{STEP 3.1:} & \textbf{Tighten the 4 Corner with Allen Key (5).} \\ \textbf{STEP 3.2:} & \textbf{Fix the Bed Slat Support Leg (E), to Bed Slat (D) as shown.} \\ \end{tabular}$

STEP 3.3: Install the bed slat (D) to side rail (F) and tighten with Csk Screw (6) as per diagram shown. (NOTE: THE SETUP MUST DONE AT THE DECIDED LOCATION FOR THE BED TO OBTAIN PERFECT STABILITY)



ASSEMBLY INSTRUCTIONS

MODEL: B850-N NIGHT STAND

(BOX 1)


BOX OF NIGHT STAND

NO	ITEM	QTY
A	NIGHT STAND	1 pc
В	BUN FOOT	4 pcs

(BOX 1) HARDWARE LIST

NO	ITEM	QTY
1	JCBC Bolt m6x50mm Blk	4 pcs
2	Spring Washer 1/4" Blk	4 pcs
3	Flat Washer 1/4"IDx13mmOD Blk	4 pcs
4	Allen Key m4x110mm With Ball Blk	1 pc

STEP 1: Open the bottom drawer and take out the Bunfoot carton (B). Assemble the Bun Foot (B) with JCBC Bolt (1), Spring washer (2), Flatwasher (3) and securing with Allen Key (4) as shown.





NOTE: MUST TIGHTEN SCREWS PERIODICALLY WITH USE SCREW WILL BECOME LOOSE CHECK TIGHTNESS OF ALL SCREW EVERY 6-8 WEEKS.