



PASSENGER DRINK HOLDER MOUNT FOR INDIAN

- WARNING** This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.
- CAUTION** This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.
- ATTENTION** This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.



Installation Instructions:

1. Park on a level surface and shut off the motorcycle. Ensure that the engine has time to cool before installation.
2. Cover areas of motorcycle around work area to protect surfaces from damage.

NOTE: Typical right side installation shown, left side installation would be similar.

3. Open trunk lid and remove existing screw shown. This will not be reused. Fig. 1
4. Insert mount and apply masking tape in the area shown. Fig. 2
5. Lay plate on top of mount, temporarily install the included 30mm long screw into place, making sure to align outer edge of plate with hinge. Fig. 3
6. Using a center punch mark each hole to be drilled. Fig. 4 Remove screw, plate, and mount before drilling pilot hole.
7. Add masking tape to prevent metal shavings from falling into unwanted areas, then drill small pilot hole at both previously marked locations. Enlarge each hole to 9/32 inch. Fig. 5

CAUTION It is highly recommended to use a vacuum to remove any drill shavings.

8. Remove tape and clean area thoroughly. Reinstall mount, plate, and the three provided screws and tighten securely. Fig. 6
9. Install drink holder following its provided instructions. Sold separately.



