

STREAMLINE™ | INSTRUCTION SHEET

POLE REPAIR INSTRUCTIONS

REF: INSTR-POLEREPAIR



Fitting a pole collar to a pole section

1. Roughen the end of the pole section with the sandpaper supplied in the kit.
2. Puncture the Penloc tube using the little red cap provided (use the red cap to keep the remaining Penloc airtight in the tube after use).
3. Pre-mix equal parts of adhesive with the stirrer supplied, until the colour is a consistent grey.
4. Apply the solution generously on to the prepared section.
5. Slide and turn the collar at the same time onto the glue on the pole section until the collar seats against the section end. This action ensures a good spread of adhesive around the whole section.
6. Remove excess adhesive with a clean wipe.



For best results allow at least 24 hours for the adhesive to fully cure before use.