

#### **INSTALLATION INSTRUCTIONS FOR PART 99-5716**

#### **APPLICATIONS**

## Ford/Mercury 2000-2003 99-5716




#### **KIT FEATURES**

- ISO DIN head unit provisions
- Incorporates factory climate controls into installation

#### **KIT COMPONENTS**


- A) Integrated mounting kit B) ISO Faceplate C) Tuner bypass D) ISO Brackets
- E) (2) #8 x 3/8" Phillips pan head screws



В



C



D



F



WIRING & ANTENNA CONNECTIONS (included)

Wiring Harness:

- Included with dash kit
- Antenna Adapter:
- 40-FD10

#### **TOOLS REQUIRED**

• 86-5618 Head unt removal keys • Torx head screwdriver





REV. 02/21/12



#### **Table of Contents**

### **Dash Disassembly**

- Ford Taurus 2000-2003	3
- Mercury Sable 2000-2003	3
Kit Preparation	
- Ford Taurus 2000-2003	4-5
- Mercury Sable 2000-2003	4-5
Kit Assembly	
- ISO head unit provision	6
- DIN head unit provision	7
- Trunk provision	8

CAUTION: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

Note: Refer to the instructions included with the aftermarket radio.



#### **KNOWLEDGE IS POWER**

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry.

Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.



Metra recommends MECP certified technicians




### Dash Disassembly 99-5716

# Ford Taurus/Mercury Sabel 2000-2003

- **1.** Using the 86-5618 removal keys pull the factory radio/climate control panel from the dash. (Figure A)
- 2. Disconnect the vacuum hose harness and connectors from the audio system, blower motor switch, A/C dampener door switch, and potentiometer.
- **3.** Remove the panel.

Continued to kit preparation



(Figure A)




#### Kit Preparation 99-5716


# Ford Taurus/Mercury Sabel 2000-2003

- Turn the factory climate control dials into a vertical position and pull the dials off. (Figure A)
- 2. Remove (2) 5/16" hex head screws securing the temperature/fan control switches and remove switches. Unclip the climate control switch and remove. (Figure B)
- **3.** Mount switches to the back of the integrated mounting kit with the (2) supplied #8 x 3/8" Phillips pan head screws. (Figure C)
- **4.** Holding the climate control dials in a vertical position insert the dials onto the posts of the mounted switches and secure. (Figure D)


Continue on next page




(Figure B)



(Figure C)



(Figure A)



(Figure D)




### Kit Preparation 99-5716


# Ford Taurus/Mercury Sabel 2000-2003

- **5.** Remove (2) Torx head screws securing the mounting clips to the sides of the factory radio/climate control panel and remove the clips. (Figure E)
- **6.** Mount the clips to the integrated mounting kit with the same Torx head screws. (Figure F)

Continue to kit assembly



(Figure E)




(Figure F)




### Kit Assembly 99-5716

## **ISO** head unit provision

- **1.** Snap the ISO Faceplate into the radio opening. (Figure A)
- **2.** Attach the ISO Brackets to the inner lip of the radio opening. (Figure A)
- 3. Slide the head unit into the radio opening, align the holes in the head unit with the holes in the ISO Brackets and mount the unit to the brackets with the screws supplied with the unit. (Figure A)
- 3. Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Re-connect the negative battery terminal and test the unit for proper operation.
- **4.** Reassemble dash in reverse order of disassembly. (Figure B)



(Figure A)




(Figure B)




### Kit Assembly 99-5716

## **DIN** head unit provision

- 1. Slide the DIN cage into the Integrated Mounting Kit and secure by bending the metal locking tabs down. (Figure A)
- 2. Slide the aftermarket head unit into the cage and secure. (Figure A)
- 3. Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter from Metra or AXXESS. Re-connect the negative battery terminal and test the unit for proper operation.
- **4.** Reassemble dash in reverse order of disassembly. (Figure B)



(Figure A)



(Figure B)



#### Kit Assembly 99-5716

## Trunk provision


- 1. Open the trunk, remove (4) pop-clips from the driver's side trunk liner. Remove liner. (Figure A)
- 2. Locate the factory tuner on the wall of the trunk and disconnect the speaker and antenna plugs. (Figure B)

**Note:** It is not necessary to remove the tuner.


- **3.** Plug the 70-5715 into the unit speaker plug and the antenna extension lead into the unit antenna plug.
- **4.** Slide the extension harness through the space in the back seat between the seat back and seat bottom.
- Unclip the rocker trim, tuck the extension harness under the carpet and stretch the harness to the back of the dash.

**Note:** Replace the rocker trim when completed.

- **6.** Splice speaker leads on the extension harness into the rear of the aftermarket head unit.
- 7. Plug the factory wiring harnesses into the switch connectors (previously mounted in Step 2) and audio connectors on the back of the integrated mounting kit.



(Figure A)



(Figure B)



#### **INSTALLATION INSTRUCTIONS FOR PART 99-5716**





99-5716

2000-2003

# FORD TAURUS/MERCURY SABLE

With Manual A/C



Electroluminescent light source duplicates OEM technology to provide a factory look and maintenance free durability that outlasts bulbs.

La fuente de luz electroluminiscente duplica la tecnología del fabricante de equipo original para proveer un aspecto de fábrica y durabilidad libre de mantenimiento que dura más que los focos.

REAR DEFROST SWITCH

Laser etched, LED defroster switch for an OEM look

Interruptor de desempañador LED, grabado a láser para un aspecto de fabricante de equipo original

**AUTOMOTIVE** INSTALL KIT



INSTALACIÓN AUTOMOTRIZ

STEP BY STEP INSTRUCTIONS



PASO A PASO

ALL BRACKETS INCLUDED



TODOS LOS SOPORTES

**HEAVY DUTY** 



**PLÁSTICO ABS RESISTENTE** 

**FACTORY STYLE** 



ESTILO DE FÁBRICA






TRIM PLATE











**TURBO KIT** 



Para más información







99-5716

2000-2003

# FORD TAURUS/MERCURY SABLE

With Manual A/C

AUTOMOTIVE INSTALL KIT





HEAVY DUTY ABS PLASTIC

**FACTORY STYLE TEXTURES** 









INSTALACIÓN **AUTOMOTRIZ** 



INSTRUCCIONES **PASO A PASO** 



**TODOS LOS** SOPORTES



PLÁSTICO





Utilizes the factory heating and A/C switches

**Utiliza los interruptores** de calefacción y aire acondicionado de fábrica.



Comes complete with wire harness and antenna extension

Incluye el arnés de cableado y la extensión de la antena



LIGHT SOURCE

**Electroluminescent light source duplicates** OEM technology to provide a factory look and maintenance free durability that outlasts bulbs.

La fuente de luz electroluminiscente duplica la tecnología del fabricante de equipo original para proveer un aspecto de fábrica y durabilidad libre de mantenimiento que dura más que los focos.

REAR DEFROST SWITCH

Laser etched, LED defroster switch for an OEM look


Interruptor de desempañador LED, grabado a láser para un aspecto de fabricante de equipo original

THE INSTALLER'S CHOICE

460 Walker Street, Holly Hill, FL 32117 © Copyright 2012 - Metra Electronics Corporation For more information



Para más información



¿Tiene preguntas? Llame a la línea de ayuda



W-99-5716