



MAKE A DIFFERENCE

Rear Fender Flares

BXG.7020

(INSTALLATION INSTRUCTION)

ATTENTION • Please verify all parts are present and read instructions carefully before starting installation.
• Please feel free to contact your distributor if you have any kind of question about your purchase.




1 CONTENTS



Diver Side



Passenger Side

Qty	Part Name	Size(mm)	Picture
10	Hex Bolts	M8*25	
10	Split Lock Washer	D8	
10	Flat Washer	M8*16*1	
10	Flange Hex Lock Nuts	M8	
2	Rubber Strip	2200	

2 TOOLS REQUIRED

◆ Drive Ratchet Handle

◆ 13mm Wrench

◆ 13mm Shallow Socket

To view online instruction, please scan the QR code.



3 INSTALLATION INSTRUCTION

Rear Factory Flare Removal

Step 1

Remove the bolts located along the interior of the inner fender and the clips located in each corner of the fender.



Remove factory fender flare.

Step 2



Remove the clips along the edge of the fender that remained in the vehicle.

Step 3



Driver Side Installation

Step 4

Identify the fender flares.



The Five Installation Holes Identify

Step 5



Attach the rubber strip to the fender flare. Align it with the factory installation holes of the vehicle.

Step 6



Step 7**Fender Flare Installation**

Middle three holes first. **Do not fully tighten hardware to allow adjustability.**

- (3) M8x25 Hex Bolts
- (3) M8x16x1 Flat Washer
- (3) D8 Split Lock Washer
- (3) M8 Flange Hex Lock Nuts

**Step 8****Fender Flare Installation**

Then the both side holes. Tighten all hardware.

- (2) M8x25 Hex Bolts
- (2) M8x16x1 Flat Washer
- (2) D8 Split Lock Washer
- (2) M8 Flange Hex Lock Nuts

**Step 8****Step 9**

Repeat the same installation steps in the passenger side.

**Step 10**

The installation is complete. We hope you enjoy a wonderful off-road life with this quality Hooke Road product!

