

## Installing Holsters

### Materials needed:

- Holster (provided by PowerFlex)
- Power drill
- Drill bits (Phillips, hex, torx, flathead)
- Assorted screws for various surface types (most common are metal, brick, concrete, and drywall)

Powerflex supplies 3 holster types – standard, J-hook, and Z. Examples of each are shown below.





If the existing holster is broken but the holes are intact, simply remove the broken holster and replace with a new one.

If new holes need to be drilled, drill 4 holes then mount the holster with the appropriate screws.