

INSTRUCTIONS FOR TUB DRAIN CONVERSION TRIM KITS

1. Remove screws from old overflow plate.
2. Align screw holes on your new overflow plate and thread screws into place.
3. Insert drain wrench into drain engaging cross members and unthread the drain assembly.
4. Thread bushing into drain. (If the drain is narrow it may not need a bushing.)
5. Spread an even layer of plumber's putty around the lip of the shoe.
6. Thread shoe into drain and tighten so that the plumber's putty forms a seal.
7. Thread plug into the drain assembly.

INSTRUCCIONES PARA LOS KITS DE RECORTE DE CONVERSIÓN DEL DESAGÜE DE LA BAÑERA

1. Quite los tornillos de la placa vieja del rebosadero.
2. Alinee los orificios para tornillos de su placa nueva de rebose y enrosque los tornillos en su lugar.
3. Inserte la llave para drenajes en los travesaños de acoplamiento del drenaje y desenrosque el conjunto de drenaje.
4. Enrosque el buje en el drenaje. (Si el drenaje es estrecho, es posible que no necesite un buje).
5. Extienda una capa uniforme de masilla alrededor del borde de la zapata.
6. Enrosque la zapata en el desagüe y apriete para que la masilla forme un sello.
7. Enrosque el tapón en el conjunto de drenaje.

