

**GP Factor assumes no liability for proper or improper installation of this kit or any use of this kit with your vehicle. If you are installing this kit, you agree to these terms and assume all liability for the installation and use of this kit. GP Factor does not provide a warranty for this product against improper installation or wiring or improper battery installation. GP Factor assumes no responsibility for any damage caused to or by this product resulting from a collision or crash. Installation of this kit may void certain factory warranty items on your vehicle. If you are unfamiliar with installing parts on trucks, disassembly and reassembly of a system like this, please have a qualified GP dealer do this install.**

## **BEFORE STARTING:** READ THROUGH THIS INSTALLATION MANUAL

### **TOOLS NEEDED:**

- 4mm driver
- 7/16 Socket Wrench

### **INCLUDED IN THIS KIT:**

- X1 License Plate Mount
- X4 1/4" Washers X4 1/4" Nylon Nuts
- X1 Pack of Vibratite thread locker
- X2 M6 Flathead 25mm Screws Black
- X2 Spacers for M6 screws behind plate mount



Lorem ipsum

**STEP 1:** Remove your license plate and factory mount and all hardware exposing the factory bumper, and 2 holes where the factory M6 threaded locations are (Pictured)



**STEP 2:** Take the included spacers, and place them behind the plate in the gap on each screw location where you will screw in the provided M6 flat head screws and the plate mount.



**Step 3:** Using the provided M6 Flat Head screws, vibratite, and your 4mm Allen tool, attach the bracket to your factory bumper. hand tighten with a 1/2 turn after.



**STEP 4:** Attach your license plate using the provided 1/4" washers and nuts with your 7/16 socket wrench.