Installation Guide

- 1. Wear gloves and use tin snips or thicker scissors to cut the stainless steel decorative strips into the required length.
- 2. Remove the dust on the wall.
- 3. Straighten the decorative strips, peel off the adhesive and stick them on the wall.
- 4. For walls that are difficult to stick, use nail-free adhesive.

