Step 1: Unfold the preassembled steel frame



Step 2: Fix the canopy with velcro straps at the corners

Step 3: Adjust the height for preferred shade coverage

