

fingers.co.in



PowerMatrix-G6

# FASHION PC CASE

Installation Guide



# Hard Disk Installation Steps

1. Remove the left side glass panel and right side metal panel of the cabinet.



2. Place the HDD/SSD in the HDD/SSD slot provision and fix it with screws



3. Cover the panel and fix it with the thumb screws.



Ver.: 1.0.0

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice. • All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on [www.fingers.co.in](http://www.fingers.co.in) • This product falls under e-waste (Management & Handling) Rules, 2011. For proper disposal method, visit our website [www.fingers.co.in](http://www.fingers.co.in)

