

Palette

QUICK-REPAIR PUTTY

USE & CARE INSTRUCTIONS

- Surface area should be clean and free of debris
- Identify the color that best matches your repair
- Knead the tube thoroughly for at least 20 seconds before use



Cut tip to desired bead size
and apply the filler evenly



Use a putty knife to distribute
into gaps, nicks and scratches

- Wipe off excess with a damp rag
- Do not allow excess filler to dry onto surrounding flooring
- Allow to dry for at least 1 hour

Gray
PC7728

Dark Brown
PC7732

Brown
PC7725

Tan
PC7730

Greige
PC7740

Natural
PC7741

Black
PC7743

White
PC7742