



CLEARMIRROR

www.clearmirror.com

CLEARMIRROR
**WALL-MOUNT
SHOWER SHELVES**

CLEARMIRROR WALL-MOUNT SHOWER SHELVES

Please feel free to contact us with any questions
you may have about ClearMirror products.

Phone: **651.251.9036**
Email: **sales@clearmirror.com**

Stylish and the ideal companion to your fog-free Shower ClearMirror.
Installation is easy with no drilling required.

- 1** Clean the shower wall and dry.
- 2** Determine general location for shelf. Use a level and a pencil to mark a straight line for the mounting location.
- 3** Use the provided rubbing alcohol wipes to clean the area where the VHB tape will contact the wall. Allow at least 1 minute to dry.
- 4** Apply 3M Primer:
 - a. Shake before opening.
 - b. Break pen by squeezing on the black dot.
Primer will soak into the foam tip.
- 5** Apply primer to the area where VHB tape will contact the wall. Allow 5 minutes to dry.
- 6** Peel off the protective layers from the VHB tape (located on the back of the shelf).
- 7** Mount the shelf to the wall using your pencil mark guides. Use a small level placed on the top of the shelf to help with orientation.
- 8** Press firmly for 1 full minute to ensure the adhesive has a good contact with the shower wall. The harder and longer you press, the better the adhesive will work.
- 9** Do not use the shower for 24 hours.
- 10** Adhesive must fully dry before putting weight on the shelf. Allow for 72 hours to pass before putting items on the shelf.

NOTE: Total load of product on shelf not to exceed 8 pounds.