



# PUSH HANDLES

## INSTALLATION INSTRUCTIONS

1

Push on the fabric to locate the threaded inserts imbedded in the back of the seat as shown.



2

Using a soldering iron, burn access holes through the fabric and padding in alignment with the threaded inserts.

**NOTE:** If you purchased the Push Handles with the chair, the holes will already be there and you may disregard steps 1 & 2.



3

Secure the handle tubes as shown using a #2 screwdriver and the screws provided.

Tightly secure the handle tubes to the seat back.

