

TB51 Flexi Pipe Adapter - 3/8" tubing

The new TB51 is used in place of the S46 Saddle tapping valve to connect your Sapphire SL33 or SL33-D to the cold water supply via braided hose.

Installation Process

1. Use plumbers tape on all the threads as you assemble the connector.
2. Screw valve with blue handle into the flexi pipe connector.
3. Screw the connector to the flexi pipe cold water line at both ends.
4. Place small nut over white 1/4" tubing and push tubing over the valves nozzle. Tighten the nut to secure the tube.
5. Adjust water flow rate with handle to 2L/min.
Approx. 4L/min = full turn
Approx. 2L/min = half turn



**Adjust flowrate to 2L per min,
use red handle.**