



Use and Care Guide 46 IN SINGLE UPRIGHT

Item 1008 120 218 Model 46391PHLHD





4

Safety Information

W

WARNING: For more secure application mounting to wall stud is recommended. Ensure mounting is stable and strong enough to support intended weight. If mounting to surfaces other than wood, use appropriate hardware. Hollow wall installation is not recommended.

TOOLS REQUIRED









Power drill Stud finder Tape measure Rubber mallet







Phillips screwdriver

Pencil

Leve

INSTALLATION HARDWARE


Brackets, shelves and hardware are sold separately

Description	Quantity	Quantity			
#8 2 in. Screws	Upright Length				
&mmmm-		24 in.	36 in.	46/48 in.	68 in.
	Screw Qty	3	4	5	7

Installation

1 LOCATING WALL STUD

- Mark locations on the wall stude at the desired height.
- □ Use a level to ensure the holes are even horizontally.




2 SECURE 1ST UPRIGHT

□ Secure 1st upright to wall studs using #8 2 in. screws.




3 LEVEL THE NEXT UPRIGHT HORIZONTALLY

- Mark holes. Max spacing 16 in. from center to center of upright.
- Repeat step 2 to secure 2nd upright to wall studs or drywall.



4 TAP THE BRACKET

- Place the bracket horizontally into the upright and tap it tight with rubber mallet.
- Confirm the bracket is at the same height on each upright to ensure the shelf will be level once installed.



5 ADDING THE SHELVES

- Check that all brackets are level and place the shelf onto them.
- □ Secure the shelves to the brackets.

