

16255

QUICK RATCHET CONDUIT CLAMP FOR QB1 MOUNTING KITS



A DIVISION OF QUICKSCREWS INTERNATIONAL CORP

INSTALL INSTRUCTIONS



RECOMMENDED MATERIALS

- ½" Wrench
- Flat Head Screw Driver



INSTALLATION INSTRUCTIONS

1. Before placing the nut on the L-Foot, insert the Quick Ratchet Conduit Clamp onto the Bolt
2. Place the nut and tighten
3. Run the conduit
4. Close the Quick Ratchet Conduit Clamp to secure the conduit
5. To open or readjust, insert a flat head screw driver into the slot to release the ratchet

