



Ram 1500 Crew Cab Ram 3500 Mega Cab

Floor Liner trim patterns vary per vehicle make and model.



STEP ONE

Remove Floor Liner from box and allow it to lay out in a warm area. This allows the liner to regain its custom shape after being rolled up for shipping.



STEP TWO

Trim as shown by using sharp scissors or a carpenter's knife to cut along crevice in liner to remove area at top for vehicles with front bench seat.

Check Retention Hooks: customers whose vehicle has a single retention hook on the driver side should use a blade to cut open the scored area in the floor liner which is located off centered in the lower portion of the liner to accommodate for the hook.

Not all vehicles have a single retention hook. If your vehicle does not have a single retention hook, DO NOT cut the floor liner.



1-Piece driver and passenger side floor liner.