



## INSTALLATION INSTRUCTIONS

### Maverick R C&R Racing Radiator

SKU(s): 804FC0337

#### INCLUDED PARTS

(1) Radiator
(1) Hardware Kit

#### REQUIRED TOOLS

8, 10mm Socket
T-30 Socket
Pinch Clamp Tool
Rags & Catch Pan



WE'D LOVE TO HEAR FROM YOU - LEAVE A REVIEW & STAY CONNECTED! @ f d



## INSTALLATION INSTRUCTIONS

**Step 1:** Remove the hood bezel, 4 snap tabs.



Figure 1

**Step 2:** Remove (4) T-30 screws holding the front hood plastic.




Figure 2

WE'D LOVE TO HEAR FROM YOU - LEAVE A REVIEW & STAY CONNECTED!   



## INSTALLATION INSTRUCTIONS

**Step 3:** Remove (2) T-30 screws on the upper firewall access panel, on both sides.



Figure 3

**Step 4:** Slightly pull back on the access panel, underneath you will find a 10mm bolt with a large plastic washer. Remove on both sides.



Figure 4



Figure 5

WE'D LOVE TO HEAR FROM YOU - LEAVE A REVIEW & STAY CONNECTED! @ f d

**Step 5:** Remove the headlight access panel, (3) 8mm screws, (1) T-30, then unclip the panel from the plastic support, on both sides.




Figure 6

**Step 6:** Underneath the hood by the shock, remove (1) 10mm screw with large washer, both sides.



Figure 7





## INSTALLATION INSTRUCTIONS

**Step 7:** Remove (2) T-30 screws on the lower front valance, on both sides.



Figure 8

**Step 8:** Remove (2) T-30 screws underneath the front grill. Pop the front grill out, held in by (4) clips.



Figure 9

WE'D LOVE TO HEAR FROM YOU - LEAVE A REVIEW & STAY CONNECTED!   

**Step 9:** With the grill removed, on top (located by the camera) remove (2) T-30 screws.



Figure 10

**Step 10:** Slightly pry up on the front clip, this will gain you access to (1) T-30 behind the headlight, on both sides.



Figure 11

**Step 10 Continued:** Remove T-30 screw, on both sides.



Figure 11

**Step 11:** Pull the front clip forward, cut headlight wire harness zip ties. Unplug head light, fang light, and blinker lights (if equipped). On both sides. Remove front clip.



Figure 12





## INSTALLATION INSTRUCTIONS

**Step 12:** Pinch off both radiator hoses, cut the pinch clamp on the lower hose and remove. Place a drain pan underneath. When done draining, take the caps off the new radiator and place on the OEM radiator.



Figure 13



Figure 14



Figure 15

WE'D LOVE TO HEAR FROM YOU - LEAVE A REVIEW & STAY CONNECTED!   



**Step 13:** Remove the pinch clamp on the radiator overflow, remove hose.



Figure 16

**Step 14:** Remove the (4) 10mm bolts holding the radiator to the frame. NOTE: the top (2) bolts have nuts and aluminum spacers. Don't lose these.




Figure 17

**Step 15:** Slightly pull the radiator away from the frame, unplug the fan connectors and push darts holding the harness. Remove the radiator.



Figure 18

**Step 16:** Transfer the lower support and fan shroud over to the new radiator.



Figure 19

**Step 17:** Install the new radiator onto the car, use OEM hardware to fasten down. Install the radiator hoses and use supplied 36.1mm pinch clamps on the large hoses and 13.3mm pinch clamp on the overflow hose.



Figure 20

**Step 18:** Reinstall all parts in reverse order, fill the coolant reservoir and start the vehicle, let it reach running temperature, add coolant if needed. Check for leaks.