

L-Series Track Tie-Down Anchor Rails

Install Instructions

Parts Included:

- (2) or (4) L-Series Track Anchor Rails *(option dependent)*
- (4) or (8) L-Series Single Stud L-Series Anchor Fittings
- (4) RailTrax Bolts *(Tundra only)*
- (1) TP50 (Torx Plus 50) 3/8" Drive *(Tundra only)*

Step 1: Remove the OEM bed bolts utilizing a T55 (Torx 55) drive *(see photo 1).*

Note: OEM bed bolts that are covered in bed liner will need to be cut around the flange/washer to remove. Rest assured, the tracks will cover the exposed bed when installed.

Step 2: Position each rail between the bed bolt holes. *(see photo 2).*

Step 3: Install the bolts through each slot on the rails and secure directly to the frame of the vehicle.

Step 4: Torque each bolt to 50 ft/lb.

Note: Parts/positions being referenced are highlighted in blue in the photos.

