



## 9097V Installation Instructions

**Customer Service: 1-877-671-7011**  
**[www.allegion.com/us](http://www.allegion.com/us)**

**⚠ Caution:** Edges of aluminum parts may be sharp. Wear gloves and handle with care.

- 1. Measure and Prepare the Sweep:**  
Measure the door's butt face and cut the metal retainer to match. Leave gasketing slightly long and peen the ends to hold it in place.
- 2. Close the Door:**  
Use a self-closing mechanism (or manually) to fully close the door before positioning the sweep.
- 3. Position the Sweep:** Hold the sweep against the butt face of the closed door. Position it so it just touches the floor or the sloped bevel of the threshold it will seal against.
- 4. Attach the Sweep:** Using the sheet metal screws provided, fasten the sweep to the door. Insert screws through the center of the holes in the metal retainer. *Do not fully tighten the screws until all gasketing is in place.*
- 5. Final Check:** Open and close the door several times to confirm that the installed part does not interfere with self-closing or latching. Adjust as needed to ensure smooth operation.



Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for Application to/ with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes. Meets UL10B, UL10C and CAN4-S104-2010 Category J .17L5 9903