

RV SHOCKER™ Instructions

For use in RVs with interiors of up to 400 sq. ft. of floor space.

Important: Read all instructions before using! To guarantee success, follow all directions exactly as indicated.

Steps for Use

1. Prepare the Vehicle:

- Place the RV out of direct sunlight (e.g., in a carport or garage).

2. Unpack the Contents:

- Open the container and remove all items inside.

3. Prepare the Pouch:

- Read all information on the foil packet.
- Carefully open the packet at the notch edge to avoid damaging the contents.
- Remove the CLO2DMG Technology™ white pouch and discard the small desiccant.

4. Activate the Pouch:

- Shake the CLO2DMG Technology™ white pouch thoroughly to mix the ingredients.
- Place the pouch back into the provided container.

5. Position the Container:

- Place the container on a stable, flat surface in the center of the space to be treated.
- For added safety, place it on a plate or container lid to prevent damage from spillage, staining, or bleaching.
- Avoid placing the container directly on carpet or using it when carpets are wet.

6. Add Water:

- Using the provided measuring cup, add one full cup of cold tap water over the pouch to activate it.
- **Note:** In some cases, the product may clump over time, which could cause a popping or sputtering effect. If you hear this, there's no need to be alarmed. The product will still activate and function as intended.
- **DO NOT** put the lid back on the container until the treatment is over and the product is ready to be discarded.

7. Seal the Vehicle:

- Close all doors and windows, and lock the vehicle to prevent entry while the product is working.
- **WARNING:** Under no circumstances should any person or pet be in the vehicle while the product is active.

8. Duration of Treatment:

- Leave the product working for a minimum of 4 hours and up to 24 hours.

9. Post-Treatment Ventilation:

- At the end of the treatment, open all doors, windows, and vents for ventilation.
- Place the lid back on the product and dispose of it in an outdoor waste container.
- Allow the vehicle to ventilate for 30-60 minutes before re-entering.

Tips for Optimal Performance

- **Preparation:** Ensure all interior compartments (e.g., glove box, armrest compartments, and cabinets) are open.
- **Visors:** Pull down all visors.
- **Floor Mats:** Place floor mats on their sides.
- **Clean Up:** Clean out ashtrays and remove any trash.
- **Filters:** Change air filters.
- **Fan Setting:** Before step 9, set the fan to recycle mode and run it for 15 minutes.

- **Temperature Requirement:** Ensure the temperature is at least 50°F for effective operation.
-

Additional Information

- **Safety Note:**

The product is safe and non-toxic when used as directed. It degrades into a saline solution. All components are biodegradable and eco-friendly.

WARNING: While RV Shocker™ is non-toxic, chlorine dioxide can be an irritant. Avoid inhaling the gas directly. (Do not do a smell test.)

- To prevent spills or accidental inhalation of fumes, **activate the product only at point of use.**
 - **Do not walk with the product after activation from point A to point B,** as this may result in exposure to concentration of fumes.
 - For added safety, wear a mask and protective eyewear during handling or when ventilating the vehicle.
 - **Important:** Ensure the lid is securely placed on the container before removing it from the vehicle to avoid spills. Any spilled liquid may bleach surfaces it comes into contact with.
If the carpets have been washed, make sure the carpets are completely dry before use. Moisture in the RV will retain the chlorine dioxide molecules for a longer period of time.
-

Money-back Guarantee: Retain the foil packet and visit our FAQ page at www.BiocideSystems.com.

Contact Us:

1-877-RX BIOCIDE / 1-877-792-4624

www.BiocideSystems.com

Proudly Made in the USA!