



8644 Installation Instructions

Customer Service: 1-877-671-7011
www.allegion.com/us

⚠ Caution: Edges of aluminum parts may be sharp. Wear gloves and handle with care.

1. **Measure and Cut:** Measure the door sill at the bottom of the frame. Cut the threshold to span the full width of the opening.
2. **Notch for Jamb Stops:** If the door frame has side jamb stops, notch the threshold ends as needed to ensure a proper fit.
3. **Secure the Threshold:** Place the threshold on the sill and fasten it in place using the provided screws.
4. **Check Door Operation:** Open and close the door several times to confirm that it latches and closes smoothly. Make any necessary adjustments to the threshold.



Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for Application to/ with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes. Meets UL10B, UL10C and CAN4-S104-2010 Category J .17L5 9903