

How To Measure Outside Mount 1-in Cordless Mini Blinds

Here's how to measure for outside-mounted Mini Blinds. Ensuring there is enough space for hardware installation.

Step 1: Measure For the Width

- Measure overall window, including trim on both sides, to the nearest 1/8 of an inch.
- Add 1-1/2" on each side for better coverage.

Step 2: Measure the Height

- Measure the height inside to the nearest 1/8 of an inch between the height and lowest points.
- Include window trim, add 3" on top and 1" on the bottom, for better coverage.

Step 3: Place Order

- Round measurement UP to the closet available size for width.
- If your exact window height is not available, round UP to the next larger height.

