



SRM Quarter Turn adapter



SRM INTERNATIONAL

SRM GmbH

Rudolf-Schulten-Str. 6
52428 Jülich
Germany
Tel: +49 2461 69123-0
info@srm.de

SRM USA

720 W. Monument St.
Colorado Springs, CO 80904
USA
Phone: 719.266.4127
usa@srm.de

SRM ITALIA

Viale Carlo del Prete, 347 F
55100 Lucca (LU)
Italia
Tel: +39 0583 332036
italia@srm.de

www.SRM.de



SRM Training System



@srmtraining



srmpower

Version: V1.0 / October 2020

© 2020 SRM GmbH

All copyrights and trademarks are the property of their respective owners

NOTICE

The SRM Quarter Turn adapter ONLY supports the SRM PowerControl 8 and is made for Garmin® bike mounts with quarter turn compatibility ONLY. Garmin® Quarter Turn adapter is not included.

MOUNTING THE ADAPTER TO THE PC8

- Before mounting the SRM Quarter Turn adapter make sure the backside of the PowerControl is clean and dry. Use isopropanol alcohol (IPA) in the marked area to remove grease or other residues before installing the adapter (Fig. 1).

NOTICE

Make sure that the adapter sits flat, straight and centered on the backside of the PC8 housing, ensuring it is positioned around the raised connector. Once the 3M™ VHB™ tape has been placed, no further adjustments can be made!

- Remove the red protective liner from the tape (Fig. 2).
- Place the adapter as shown in Fig. 3 and apply pressure for at least 60 seconds. Covering the sticker on the back of the PC8 is not a problem.
- Let the adapter cure for at least 6 hours before use. The final bond strength is reached after approx. 24 hours.

INSTALLING THE PC8 TO THE BIKE MOUNT

- Align the tabs of the adapter with the bike mount notches.
- Press down lightly on the PowerControl and turn it clockwise until it locks into place.

FIG. 1**FIG. 2****FIG. 3****FIG. 4**