

Instructions / Assembly for Neoprene Rubber Seal Strip

1. Preparation

- **Tools Required:** Scissors, utility knife, measuring tape, marker, adhesive (optional).
- **Surface Cleanliness:** Ensure the installation area is dry, dust-free, and oil-free for optimal adhesion.

2. Measure & Cut

- **Determine Length:** Measure the area where the strip will be applied (e.g., door frame, pipe joint).
- **Mark & Trim:** Use a marker to mark the desired length on the strip. Cut with scissors or a sharp knife. For curves, score the backside gently to maintain flexibility.

3. Installation

- **Adhesive-Free Application:**
 - Press the strip into place (e.g., weather stripping gaps, machinery seals).
 - Secure with staples, clips, or mechanical fasteners if movement is expected.
- **With Adhesive:**

- Apply rubber-compatible adhesive to the surface.
- Press the strip firmly onto the adhesive, ensuring full contact.

4. Shaping for Specific Uses

- **Gaskets:** Cut the strip to fit between two surfaces (e.g., engine parts).
Overlap ends slightly for a continuous seal.
- **Floor Protection:** Trim to cover edges or high-traffic areas. Use multiple strips for larger spaces, overlapping seams by 1/2 inch.
- **Pipe Sealing:** Wrap the strip around pipes, overlapping edges by 1/4 inch. Secure with hose clamps for pressure applications.

5. Final Checks

- **Verify Fit:** Ensure the strip is taut, without gaps or wrinkles.
- **Test Function:** Check seals for leaks (water/oil) or vibrations (soundproofing).
- **Trim Excess:** Use a knife to remove any overhanging material.