



Saunyo**to**

S11 Instrument Screen Installation Instruction

For M3 Highland/MY Juniper



**Model 3 Highland
Installation Video**



**Model Y Juniper
Installation video**



Join Us



Parts List

- 1: screen body
2. power cord
- 3.pry tool
- 4.USB Driver
5. front camera
6. tape
- 7.threading tool



Disclaimer and Notes

Warnings and Disclaimers

Important Tips: Thank you for your support in purchasing our products. In order to protect the legitimate rights and interests of users, please read carefully and operate the product in accordance with the precautions for use, product installation instructions and user manual before using this product.

Precautions for use

1. Before installation, please check whether the product list is complete and undamaged.
2. The installation instructions may be slightly different from the actual operation. If there are any differences, please contact us according to the actual situation.
3. Warning: Do not disassemble any parts by yourself. Any improper operation is not covered by the warranty.
4. Before installing the product, please watch the installation video and instructions.
5. Check whether the installed product is operating normally.

Front Camera Installation Instructions (option)



1. Open the front trunk and remove the 4 fixing nuts of the front trunk storage trim using a No. 10 socket tool



2. Removing the air conditioning filter protection panel and the air filter cover



3. Remove the front button trim and pull out the front button switch



4. Remove the front trunk storage box and take it out of the vehicle. (Put the removed trim panel in the front trunk storage box for easy storage)

Front Camera Installation Instructions (option)



5. Wrap the camera extension cable and threading tool with tape and pass the camera harness through the lower grille into the cabin.



6. through threading tool from the front trunk's strut button.



7. Tear off the 3M adhesive post of the camera, clean the bumper and stick it on, or use the delivered screws to fix the



8. Insert the threading tool through the side of the rubber ring into the front passenger seat.

S11 Dashboard Screen Installation Instructions



9.Remove the front passenger door rubber (left and right side are same)



10.remove the clip on the passenger door trim panel



11.Remove the passenger rectangular trim panel



12.Remove the footwell light panel under the passenger seat and disconnect the plug

S11 Dashboard Screen Installation Instructions



13. Pull out the wiring strap from the passenger side (for front camera installation step 8 the next step)



14. Use a prying tool to pry open the left and right sides of the dashboard, and take it out of the car.



15. Plug our screen's AMD canbus plug with original vehicle's A-pillar power connection



16. Plug our screen AMD's 12V male plug with original vehicle's A-pillar 12V Female plug

S11 Dashboard Screen Installation Instructions



17. Plug our screen AMD's 12V female plug with original vehicle's A-pillar 12V male plug



18. Use the tape to wrap the power cord plug extension wire and camera plug extension wire with the threading tool and pass the threading tool through the hole of the triangle into the instrument panel.



19. Run the wire through the instrument position above the front steering wheel

S11 Dashboard Screen Installation Instructions



20. connect the power cord plug with our screen's power plug. (the yellow plug is for front camera's)



21. run the cable well, and align the air outlet of our screen with the air outlet of the original car



22. Insert the instrument into the instrument panel



23. Test whether the product is working properly. If there is no problem, restore the original car dashboard trim and other parts