



## Bolide QuickConnect Set-Up Guide



Connect NVR WAN Port to Internet Service Provider ( ISP )  
Modem via Network Cable

On Mobile Device, Download and Install  
" Bolide QuickConnect from the Apple App Store  
or Google Play Store



Press  
Main Menu



Select  
" Device List "



Select  
" + " To Add  
Device,  
Then  
Select  
" IPC/NVR/DVR "



Select  
" Manual Add ".  
Allow Camera  
Use If Prompted



Scan QR Code Located On Recorder



Once Connected,  
DVR / NVR  
Will Appear  
On Main View  
Device List.  
Select A Recorder  
To Display