

Indoor Unit Condensate Pump Installation

- Use the #3 terminal wire for the float switch
- Wire colors may vary, insure you are wiring according to each wires function.

