



MADJAX 03-167 Grab Handle Instruction Manual

[Home](#) » [MADJAX](#) » MADJAX 03-167 Grab Handle Instruction Manual 

MADJAX 03-167 Grab Handle



Contents

[1 INSTALLATION INSTRUCTIONS](#)

[2 Documents / Resources](#)

[2.1 References](#)

[3 Related Posts](#)

INSTALLATION INSTRUCTIONS

03-168: One Piece Automotive Style Grab Handle

STEP 1

Insert allen head bolt into the grab handle and thread on the 'T' nut onto the end of the bolt.



STEP 2

Align the 'T' nuts with the inside wide track as shown.



STEP 3

Using a 6mm allen wrench, tighten the allen head bolt ensuring the 'T' nut engages on the triple track top.



STEP 4

Tighten the allen head hand tight to ensure the grab handle is secure to the top and use supplied plugs to cover bolt holes.



STEP 1

Install the 'T' studs into the inside wide track and turn to engage with track.

**STEP 2**

Place grab handle mounting bracket onto the 'T' studs with the flat side facing out, as shown in Step 3.

STEP 3

Thread the supplied locknut onto the 'T' studs as shown and adjust the grab handle to desired width.



STEP 4

Using a 13mm socket, hand-tighten down the locknut securely, ensuring the 'T' stud is fully engaged with the track.



Note: Self-tapping screws included for optional installation locations.

MADJAX[®]

GRABHANDLES

Documents / Resources



[MADJAX 03-167 Grab Handle](#) [pdf] Instruction Manual
03-167 Grab Handle, 03-167, Grab Handle, Handle

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.