

motepro Digi-Code Coding Device Instructions

Home » motepro Digi-Code Coding Device Instructions

motepro Digi-Code Coding Instrucons

Both Digi-Code and Mul-Code are electronically the same.

MULTI-CODE Switches: UP for ON DIGI-CODE Switches: DOWN for ON

- 1. Open both the working original remote and the new remote to reveal two x 10 switch banks (L/H Bank = L/H Buon) on the circuit board or one bank of 10 switches for a single buon remote.
- 2. Copy the switches exactly when coding Mul-Code to Mul-Code or upside down when coding Mul-Code to Digi-Code.

If no working remote is available look to the receivers on the motor/s (these are generally grey rectangular boxes aached to the motor. Remove the inspecon panels to reveal the 10 switches. This will mainly be a Mul-code receiver. Follow the steps above once you have located the switches on the receiver.

www.remotepro.com.au

WARNING

To prevent possible SERIOUS INJURY or DEATH:

- Battery is hazardous: NEVER allow children near batteries.
- If battery is swallowed, immediately notify a doctor.

To reduce risk of fire, explosion, or chemical burn:

- Replace ONLY with the same size and type battery
- DO NOT recharge, disassemble, heat above 100° C, or incinerate



Battery will cause SEVERE or FATAL injuries in 2 hours or less if swallowed or placed inside any part of the body.

Contents

- 1 Documents / Resources
 - 1.1 References
- **2 Related Posts**

Documents / Resources



motepro Digi-Code Coding Device [pdf] Instructions

Digi-Code Digicode Cloning Garage Gate Remote Control Opener Multicode, HT7, Digi-Code C oding Device, Digi-Code Coding

References

• R Garage Door Remotes | Car Remotes | Free Shipping AU Wide - Remote Pro

Manuals+,