

NEXSENS X2 Environment Data Logger Grounding Kit Instructions

Home » NEXSENS » NEXSENS X2 Environment Data Logger Grounding Kit Instructions



Figure 1: Insert the adapter into one of the threaded holes on the X2.

- 1. Place the largely included lock-washer over the larger diameter end of the threaded adapter.
 - a. Tighten the adapter into any of the available (3) threaded holes on the X2 using a 1/2" socket or hex driver.




Figure 1: Insert the adapter into one of the threaded holes on the X2.

- 2. Position the grounding lug, followed by the small lock-washer and nut on top of the threaded adapter.
 - a. Tighten down the nut using a 7/16" socket or hex driver.
- 3. Use a 5/32" Allen wrench to tighten down the ring terminal cable to the grounding lug.




Figure 3: Connection between the grounding lug and terminal cable.

- 4. Follow the PM2 quick start card to mount the X2 to the buried 2" NPT pipe or another mount.
- 5. Slip the ring terminal of the cable between the washer and lock-washer on one side of the PM2 U-bolt.
 - a. Tighten securely with a 1/2" socket or hex driver.




Figure 4: Completed X2 grounding kit assembly.



937-426-2703

www.nexsens.com


2091 Exchange Court Fairborn, Ohio 45324

Contents

1 Documents / Resources

2 Related Posts

Documents / Resources



NEXSENS X2 Environment Data Logger Grounding Kit [pdf] Instructions X2 Environment Data Logger Grounding Kit

Manuals+,